

Frame Assembly and Installation Instructions

Install is not impossible to do alone – but is easier with 2 people

We have chosen to use a two-part epoxy instead of double stick tape because we have found that double stick tape does not hold up in a moist environment such as a bathroom.

1. Clean mirror.
2. Lay the 4 lengths of frame molding face down in an open space on your floor – Each corner has been labeled with an A, B, C & D – match up each letter with its counterpart.
3. Put one of the provided screws in each hole and tighten the corner joint.
4. Test fit the frame on your mirror. The hooks that have been mounted on the top of your frame should fit right over the top edge of your mirror holding it in place.
5. Put 6 quarter sized dollops of the provided glue on mirror (see glue placement on chart below).
6. Once you have applied the glue, put your frame back up and each person should put pressure on the right and left side of frame and bottom while epoxy sets up. Should take approximately 90 seconds. Before releasing frame – make sure it doesn't pull away from mirror.

